



INTERCHANGEABLE LENSES PROVIDE MAXIMUM VISUAL PERFORMANCE

EyeSights patented design is engineered to withstand the rigorous requirements of the ANSI Z87.1-2003 high impact standard. To meet ANSI Z87.1-2003 impact standard, the lenses must remain seated in the eyewear frame when impacted by a steel projectile moving at an extremely high velocity. To insure proper eye protection, the EyeSights lens system is designed to be very secure in the frame. When changing lenses, you may experience some difficulty due to the safety rated lens mounting system. If you experience any difficulty in changing lenses, please contact Live Eyewear customer service at 800.834.2563 for additional assistance and technical questions.



INTERCHANGEABLE LENS INSTRUCTIONS

1. Firmly grip the frame and lenses as depicted in illustration A.
2. Flex the frame slightly by rotating your hands outward, freeing the lens from the frame at the bridge attachment. See illustration B.
3. Once the lenses are free from the bridge mount, firmly grip each lens and remove from the side mount.
4. Insert each new lens into the frame separately. First, insert the lens in the outside mount. See illustration C.
5. Repeat lens insertion procedure for opposite lens.
6. Firmly grip the frame and lenses together and flex the frame outward while applying downward pressure to the lenses until the bridge mount snaps into place. See illustration D.